

Zeitschrift: IABSE reports of the working commissions = Rapports des commissions de travail AIPC = IVBH Berichte der Arbeitskommissionen

Band: 13 (1973)

Artikel: A design method using weighted fractiles as design values

Autor: Paloheimo, Eero

DOI: <https://doi.org/10.5169/seals-13775>

Nutzungsbedingungen

Die ETH-Bibliothek ist die Anbieterin der digitalisierten Zeitschriften auf E-Periodica. Sie besitzt keine Urheberrechte an den Zeitschriften und ist nicht verantwortlich für deren Inhalte. Die Rechte liegen in der Regel bei den Herausgebern beziehungsweise den externen Rechteinhabern. Das Veröffentlichen von Bildern in Print- und Online-Publikationen sowie auf Social Media-Kanälen oder Webseiten ist nur mit vorheriger Genehmigung der Rechteinhaber erlaubt. [Mehr erfahren](#)

Conditions d'utilisation

L'ETH Library est le fournisseur des revues numérisées. Elle ne détient aucun droit d'auteur sur les revues et n'est pas responsable de leur contenu. En règle générale, les droits sont détenus par les éditeurs ou les détenteurs de droits externes. La reproduction d'images dans des publications imprimées ou en ligne ainsi que sur des canaux de médias sociaux ou des sites web n'est autorisée qu'avec l'accord préalable des détenteurs des droits. [En savoir plus](#)

Terms of use

The ETH Library is the provider of the digitised journals. It does not own any copyrights to the journals and is not responsible for their content. The rights usually lie with the publishers or the external rights holders. Publishing images in print and online publications, as well as on social media channels or websites, is only permitted with the prior consent of the rights holders. [Find out more](#)

Download PDF: 30.01.2026

ETH-Bibliothek Zürich, E-Periodica, <https://www.e-periodica.ch>

A Design Method using Weighted Fractiles as Design Values

Une méthode de dimensionnement utilisant des valeurs pondérées

Eine Bemessungsmethode unter Benutzung gewichteter Fraktile

Eero PALOHEIMO
Helsinki, Finland

INTRODUCTION

The theoretical basis of the design method by which weighted fractiles are used as design values was presented in [4] and it is thus unnecessary to study its derivation here in detail. The main extension by the present contribution compared with the former is the application of the method to load-effects which are variable in time. This study is included in the latter part of the paper.

There are anyhow good reasons for presenting the main principles of this design method generally first.

DESCRIPTION OF THE METHOD

We study a general case of a design problem in which the condition for failure can be described by the corresponding inequality:

$$g(X_1, \dots, X_n) \leq 0 \quad \dots (1)$$

where $g(\cdot)$ = the corresponding limit state function, obtainable from the handbooks of statics; X_1, \dots, X_n = the various quantities such as properties of materials, dimensions, loads or load-effects. All these quantities, invariable in time are random variables and we assume that their distributions are given in the standards.

As a design criterion we write

$$p_f = P(g(X_1, \dots, X_n) \leq 0) \leq p_{fa} \quad \dots (2)$$

where p_f = failure probability, which simply means that the failure probability should be p_{fa} at most. The p_{fa} - values should be given in standards and depend on the type of structure.

As will be shown later, the method can also be applied to a case when the distributions are unknown, and we define the level of reliability not by p_{fa} , but by β , defined by

$$m_Z - \beta \cdot \sigma_Z = 0 \quad \dots (3)$$

where

$$Z = g(X_1, \dots, X_n) \quad \dots (4)$$

and m_Z , σ_Z are the mean value and standard deviation of Z .

With distributions differing from the normal distribution, this simplification leads to considerable errors, in the aimed reliability.

We write the design equation in a deterministic form

$$g(x_1^*, \dots, x_n^*) = 0 \quad \dots (5)$$

with such design values that (2) is valid. As was shown in [4] there are several combinations of values x_1^*, \dots, x_n^* which satisfy the equation (5). We choose the following values for use in (5):

$$x_i^* = m_i - \beta_i \cdot \alpha_i \cdot \sigma_i \quad \dots (6)$$

where m_i and σ_i are the mean and st.d. of X_i and the parameters α_i and β_i are defined as follows:

The parameters β_i describe the desired level of reliability, according to the form of the corresponding distribution:

$$F_i(m_i - \beta_i \cdot \sigma_i) = p_{fa} \quad \dots (7a)$$

$$1 - F_i(m_i + \beta_i \cdot \sigma_i) = p_{fa} \quad \dots (7b)$$

The parameters α_i describe the significance of the corresponding quantity and are defined as follows:

$$\alpha_i = a_i / \left(\sum_{j=1}^n a_j^2 \right)^{1/2} \quad \dots (8)$$

where

$$a_j = \beta_j \cdot \sigma_j \cdot \partial g / \partial x_j \quad \dots (9)$$

From (9) it can be noted that the significance of the different quantities is thus proportional to the distance of the p_{fa} - fractile from the mean and to the derivative $\partial g / \partial x_j$. In the design, the m_i - values are chosen so that using the design values defined by (6), (5) is valid. Choice of the design values in this way is the main principle of the design method presented.

In cases in which the distributions of the different quantities are unknown the method can easily be applied distribution-free using the following relations:

$$x_i^* = m_i - \beta \cdot \alpha_i \cdot \sigma_i \quad \dots (10)$$

where α_i is defined by (8) but

$$a_i = \frac{\partial g}{\partial x_i} \cdot \sigma_i \quad \dots (11)$$

In this case the level of the reliability is not given by p_{fa} but by β , in the way shown in (3).

CHARACTERISTICS OF THE METHOD

Before studying the application of the method in cases which also include variable quantities, it is necessary to study some special features of this method.

Firstly, using (5) and (6) as design equations, it is not necessary to know the values of α_i exactly, while

$$\left. \frac{\partial p_f}{\partial \alpha_i} \right|_{\substack{\rightarrow \\ x = x^*}} = 0 \quad \dots (12)$$

by $i = 1, \dots, n$

and therefore small variations of $\partial g / \partial x_i$, β_i and σ_i in definition of the parameters α_i do not influence the results.

It is only significant to note that always

$$\sum_{i=1}^n \alpha_i^2 = 1 \quad \dots (13)$$

With (8) and (13), the α -values can be estimated so that they correspond approximately to the significance of the various quantities. A more exact method is division of function $g(\cdot)$ into subfunctions.

If we assume that Y_i , $i = 1, \dots, m$ are the subfunctions of $g(\cdot)$, according to (6), we obtain

$$y_i^* = m_i - \beta_i \cdot \alpha_i \cdot \sigma_i \quad \dots (14)$$

This is, however, only a p_{fai} - fractile of the quantity Y_i and we can treat the quantities X_{ij} included in it in a way analogous to the way Y_i was treated. We then obtain

$$x_{ij}^* = m_{ij} - \beta_{j/i} \cdot \alpha_{j/i} \cdot \sigma_{ij} \quad \dots (15)$$

where

$$F_{ij}(m_{ij} - \beta_{j/i} \cdot \sigma_{ij}) = p_{fai} \quad \dots (16a)$$

$$1 - F_{ij}(m_{ij} + \beta_{j/i} \cdot \sigma_{ij}) = p_{fai} \quad \dots (16b)$$

$$\alpha_{j/i} = a_{j/i} / \left(\sum_{k=1}^n a_{k/i}^2 \right)^{1/2} \quad \dots (17)$$

where

$$a_{k/i} = \frac{\partial y_i}{\partial x_{ik}} \cdot \beta_{k/i} \cdot \sigma_{ik} \quad \dots (18)$$

Should Y_i and X_{ij} have approximately the same distribution, we have

$$\beta_{j/i} = \beta_i \cdot \alpha_i = \beta_{ij} \cdot \alpha_i \quad \dots (19)$$

where β_{ij} is defined as in (7). In this way we obtain the design values

$$x_{ij}^* = m_{ij} - \beta_{ij} \cdot \alpha_i \cdot \alpha_{j/i} \cdot \sigma_{ij} \quad \dots (20)$$

where β_{ij} is defined as in (7), $\alpha_{j/i}$ as in (17) and α_i by (8) where

$$\alpha_j = \frac{\partial g}{\partial y_i} \cdot \beta_j \cdot \sigma_j \quad \dots (21)$$

It should be noted that the definition of α_i - values is approximate but because of (12) the small errors are not significant.

APPLICATION TO VARIABLE LOADS

All the quantities in the design criterion (1) are assumed to have distributions which remain invariable with time. We will now study a case in which some of these quantities are variable in time.

We first make a limitation concerning the type of these quantities, the variable load-effects. We assume that they all have the same dimension i.e. they are all e.g. moments or normal forces. Secondly, we assume that all the variable quantities have, to use the terminology of Ferry Borges [3], the same duration of elementary interval and the same number of independent repetitions. These are both considerable simplifications of the general case treated earlier in [1].

We assume now that the number of independent repetitions, r , is given, as well as the types of the momentary distributions of the variable loads as fundamental information in standards. To be on the safe side, it seems better to assume that the number r is rather small and to define the momentary distribution as the distribution of the maximum-value in the corresponding, arbitrary elementary interval.

The definition of the design values will now be made stepwise, so that the invariable quantities are first combined with the extreme-value of the combination of the different, momentary variable load -effects.

The momentary distribution of the combination can be trivially defined from the distributions of the various, usually additional quantities. After that we only need define approximately the mean and standard deviation of the distribution of the extreme-value.

We combine this approximate distribution with the distributions of the invariable quantities, and obtain with (8) the α -parameters for the different invariable quantities and for the extreme-value of the combination of the variable quantities.

The design values of the invariable quantities can then be defined with (6). We further study the approximate design value of the extreme value of the sum of the variable quantities:

$$y^* = m_y - \beta_y \cdot \alpha_y \cdot \sigma_y \quad \dots (21)$$

In (21) all the parameters are approximate, but using (7) we know that

$$1 - F_y(m_y + \beta_y \cdot \sigma_y) = p_{fa} \quad \dots (22)$$

According to the form of the distribution we may now solve

a new probability:

$$1-F_y(m_y + \beta_y \cdot \alpha_y \cdot \sigma_y) = p_{fay} > p_{fa} \quad \dots (23)$$

It should be noted that in many cases the relation p_{fay} : p_{fa} is independent of the values m_y and σ_y , e.g. with the extreme type 1 distribution. Because of (12) and (13) the slight errors in α are not significant. For these reasons we can note that in spite of the approximate way of defining α_y , we have a rather reliable value, p_{fay} as a basis for the determination of the design values of the variable quantities.

The second step is to study the momentary combination of the different variable loads. The p_{fay} - fractile with the extreme distribution corresponds to

$$1-(1-p_{fay})^{1/r} \approx p_{fay}/r - \text{fractile} \quad \dots (24)$$

with the momentary distribution. We denote this with

$$p_{fay}/r = p_{fam} \quad \dots (25)$$

The design values of the different variable quantities may now be defined as earlier:

$$x_i^* = m_i - \beta_i \cdot \alpha_i \cdot \sigma_i \quad \dots (26)$$

where m_i and σ_i are the mean value and the standard deviation of the different momentary distributions. The other parameters are defined as follows:

$$1-F(m_i + \beta_i \cdot \sigma_i) = p_{fam} \quad \dots (27)$$

$$\alpha_i = a_i / \left(\sum_{j=1}^m a_j^2 \right)^{1/2} \quad \dots (28)$$

$$\text{where } a_j = \frac{\partial y}{\partial x_j} \cdot \beta_j \cdot \sigma_j \quad \dots (29)$$

in which y simply means the sum $x_1 + \dots + x_m$, and m is the number of the variable loads.

EXAMPLE

We now study a simple function $g(\cdot)$ with resistance R , in-variable load-effect S_g , and two variable load-effects S_{p1} and S_{p2} :

$$g(\cdot) = R - S_g - S_{p1} - S_{p2} \leq 0 \quad \dots (30)$$

We take as fundamental information, which is supposed to be given in the standards, the following values:

$$p_{fa} = 10^{-6} ; r = 100$$

Further, we assume that the variation-coefficients and the types of distributions are given in table 1. The dependence p_{fa}/β is given in fig. 1.

		Type of distr.	m_i	v_i
R	X_1	Log. normal	6,0	0,10
S _g	X_2	Normal	1,0	0,05
S _{p1}	X_3	Extreme I	1,0	0,15
S _{p2}	X_4	Extreme I	0,5	0,10

Table 1

	m_i	β_i	σ_i	$\beta_i \cdot \sigma_i$	α_i	x_i^*
X_1	5,9	3,8	0,59	2,24	0,81	4,08
X_2	1,0	4,7	0,05	0,24	0,08	1,02
$X_3 + X_4$	2,1	10,4	0,16	1,67	0,59	
X_3	1,0	9,7	0,15	1,46	0,95	2,39
X_4	0,5	9,7	0,05	0,49	0,32	0,66

Table 2

 $\Phi = 2,36$

	m_i	β_i	σ_i	$\beta_i \cdot \sigma_i$	α_i	x_i^*
X_1	5,0	3,8	0,50	1,90	0,75	3,57
X_2	1,0	4,7	0,05	0,24	0,10	1,02
X_3	1,0	10,4	0,15	1,56	0,62	1,97
X_4	0,5	10,4	0,05	0,52	0,21	0,61

Table 3


 $\Phi = 2,00$ 

Fig. 1.

Table 4

 $\Phi = 2,40$

We first obtain as mean and standard deviation of $(S_{p1} + S_{p2})_e$:

$$m = 2,1 ; \sigma = 0,16$$

where index e indicates the extreme. According to (25) and (27) we obtain $p_{fam} = 4 \cdot 10^{-6}$; $\beta_3 = \beta_4 = 9,7$ and the results with (26) are given in table 2.

After this, the same example is calculated in two different ways.

Firstly, by studying only the combination of the momentary load-effects. This is a kind of lower-bound solution which approaches the "exact" solution with small values of r . The results of this calculation are given in table 3. Secondly, we study the combination of the distributions of the extreme values, which contrarily to the former case is an upper bound solution and is approached by the "exact" solution in cases in which the significance of the variable loads is concentrated in one of them. In our example, it can be seen that the significance of quantity X_3 is superior in relation to X_4 and therefore the results in table 2 and table 4 are rather close to each other.

The differences between the cases may be described by the fictive central safety-factors Φ corresponding to the mean values obtained in the different cases.

CONCLUSIONS

The present design method implies standardized distributions for the most usual quantities needed in the design of structures. This will anyhow be a requirement in future irrespective of the type of design method chosen. Statistical research on the types of distributions of the various quantities is therefore necessary and useful.

The method has several applications, some of which are more exact but complicated and the others which are simpler. These will be presented on a larger scale in another paper to be published later.

LITERATURE

- [1] Ferry Borges, J - Castanheta, M: Structural Safety, Course 101, 2nd Edition, Laboratorio Nacional de Engenharia Civil, Lisbon, March 1971
- [2] Lind, N: Consistent partial safety factors, Journal of the structural division, ASCE, Proc. Paper 8166, June 1971
- [3] Paloheimo E: On the reliability of structural elements and structures, Helsinki University of Technology, Research Paper 33, Helsinki 1970
- [4] Paloheimo E: Eine Bemessungsmethode, die sich auf variierende Fraktile gründet, Beitrag zur Arbeitstagung, Deutscher Beton-Verein, Berlin 1973

SUMMARY

A statistical design method is presented which is characterized by using weighted fractiles as design values. This paper gives special attention to the application in which quantities invariable in time are combined with quantities variable in time, primarily load-effects. An example is also presented to illustrate the method.

RESUME

On présente une méthode statistique de dimensionnement utilisant des valeurs pondérées en-dessous d'un certain seuil de la courbe de fréquence (courbe de Gauss) comme grandeurs de dimensionnement. Ce travail traite tout spécialement le cas de grandeurs invariables dans le temps combinées avec des grandeurs variables, en premier lieu les influences de la charge. Un exemple numérique est présenté pour illustrer la méthode.

ZUSAMMENFASSUNG

Es wird eine statistische Bemessungsmethode gezeigt, die durch gewichtete Fraktile als Bemessungsgrössen charakterisiert ist. Die Abhandlung beachtet speziell jene Anwendung, bei der die zeitunabhängigen Grössen mit zeitabhängigen Grössen kombiniert werden, hauptsächlich bei Belastungseffekten. Ein Beispiel veranschaulicht die Methode.

Leere Seite
Blank page
Page vide