

Zeitschrift: Mitteilungen aus Lebensmitteluntersuchungen und Hygiene = Travaux de chimie alimentaire et d'hygiène
Herausgeber: Bundesamt für Gesundheit
Band: 99 (2010)
Heft: 1

Artikel: "Cleaning in place" process analysis
Autor: Brunner, John
DOI: <https://doi.org/10.5169/seals-982060>

Nutzungsbedingungen

Die ETH-Bibliothek ist die Anbieterin der digitalisierten Zeitschriften auf E-Periodica. Sie besitzt keine Urheberrechte an den Zeitschriften und ist nicht verantwortlich für deren Inhalte. Die Rechte liegen in der Regel bei den Herausgebern beziehungsweise den externen Rechteinhabern. Das Veröffentlichen von Bildern in Print- und Online-Publikationen sowie auf Social Media-Kanälen oder Webseiten ist nur mit vorheriger Genehmigung der Rechteinhaber erlaubt. [Mehr erfahren](#)

Conditions d'utilisation

L'ETH Library est le fournisseur des revues numérisées. Elle ne détient aucun droit d'auteur sur les revues et n'est pas responsable de leur contenu. En règle générale, les droits sont détenus par les éditeurs ou les détenteurs de droits externes. La reproduction d'images dans des publications imprimées ou en ligne ainsi que sur des canaux de médias sociaux ou des sites web n'est autorisée qu'avec l'accord préalable des détenteurs des droits. [En savoir plus](#)

Terms of use

The ETH Library is the provider of the digitised journals. It does not own any copyrights to the journals and is not responsible for their content. The rights usually lie with the publishers or the external rights holders. Publishing images in print and online publications, as well as on social media channels or websites, is only permitted with the prior consent of the rights holders. [Find out more](#)

Download PDF: 05.08.2025

ETH-Bibliothek Zürich, E-Periodica, <https://www.e-periodica.ch>

“Cleaning in Place” Process Analysis*

John Brunner

Nestlé S.A., Avenue Nestlé 55, CH-1800 Vevey

e-mail: john.brunner@nestle.com

Summary

The presentation on CIP (Cleaning in Place) Process Analysis has 4 parts.

The first part describes the cleaning process from the view of the dairy industry. The target of the CIP process is to remove food residues and dirt. For this, the 6 “Ts” are essential: Turbulence, Time, Temperature, Titration, Technology and Training.

In the second part the fishbone diagram for problem solving is used with the 4 “Ms”: Man, Method, Material and Machine. The more automated a line is, the more important the human factor becomes. For this, training is the key word. Two video clips are shown, since for the understanding images are worth more than 1000 words. The first video clip shows 3 different velocities in a glass tube with changing diameter. The cleaning effect is only sufficient with a velocity of at least 1.5m/s. The second video clip shows two different dead ends. Cleaning with CIP can be only done efficiently in dead ends with a length of less than 1.5 times the diameter.

In the third part, a selection of analytical laboratory methods, which are often proposed, is looked at more critically. The methods are COD (Chemical Oxygen Demand), TPC (Total Plate Count) and Bioluminescence ATP.

The fourth part shows new technology in turbidity measurement, which is very interesting because of the simplicity, rapidity and low costs. Finally, different aspects of sampling will be mentioned.

* Lecture presented at the conference „Hygienic Design” on September 11-12, 2008 in Zurich

CIP Process Analysis

Hygienic Design in der Lebensmittelverarbeitung

SGLUC, SGLH, SGLWT, SVIAL Fachtagung

11./12. Sept 2008 ETH Hönggerberg, Zürich

Dr. John C. Brunner

Nestlé Central Operation Unit Quality Management




JCB
November 17,
2010 1

Content

- CIP process
- The human factor
- Analytics overview
- Turbidity

JCB
November 17,
2010 2



CIP Process

- The purpose of cleaning is to remove food residues and dirt .

(Where as the purpose of disinfection is to reduce the numbers of living microorganisms)

- CIP is part of the production process
- Example CIP cycles dairy industry:
 - Rinsing
 - Caustic
 - Rinsing
 - Acid
 - Rinsing

CIP, the 6 T's

Turbulence
Time **Temperature**
Titration **Technology**
Training


JCB
November 17,
2010 5

Content

- CIP process
- The human factor
- Analytics overview
- Turbidity

JCB
November 17,
2010 6

Fish bone diagram for problem solving




JCB:
November 17,
2010 7


Video Clip 1

- CIP module 2:
Turbulence in changing diameters


JCB:
November 17,
2010 8



JCB
November 17, 2010 9



JCB
November 17, 2010 10




JCB:
November 17, 2010 11

Video Clip 2


- CIP module 5

Vertical Downward Dead End


JCB:
November 17, 2010 12



JCB
November 17, 2010 13



JCB
November 17, 2010 14



JCB
November 17, 2010 15

Content

- CIP process
- The human factor
- Analytics overview
- Turbidity

JCB
November 17, 2010 16

Visual



- Concentrate on worst spots
- Looking for: no residues, no water, no "rainbow colours"
- Can be enhanced with UV lamps

+ simple

- subjective

JCB
November 17, 2010 17

Chemical Oxygen Demand (COD)




- COD (Chemical Oxygen Demand) is the amount of oxygen needed to oxidise reactive chemicals in water, typically determined by a standardised test procedure.

+ It is useful in determining the amount of organic residues in rinse water.
+ Good indication of how successful the rinsing has been

- Method that can only be done off line.
- Results are not instant – test takes 2 hours

JCB
November 17, 2010 18

Total Plate Count (TPC)



- Diluted samples are grown in a culture medium with incubation. The number of bacterial colonies that grow are then counted.

- + Useful in determining the amount of pathogens and spoilage microbes.

- + Provide relatively low limits of detection (1cfu/mL)-

- Detection limit is too low for CIP rinsing water.

- Method that can only be done off line.

- Results can only be seen in 48hrs.

JOB:
November 17, 2010 19

Bioluminescence ATP



- ATP (Adenosine Triphosphate) is the energy molecule in biological systems. A light is released when the molecule reacts with an enzyme. This light is measured in the form of Relative Light Units (RLU).

- + Rapid test for heavy contaminated/ high organic activity areas.

- + Detects micro-organisms and product residues.

- + Easy to use.

- Detection limit is too low for CIP rinsing water.

- Only indicates cleanliness for the defined area swabbed and not for the entire line or equipment.


- Inaccurate on areas with low contamination/organic activity.

- Expensive

JOB:
November 17, 2010 20

Other Methods Dairy Industry

- Temperature
- Velocity
- Analysis of organic and mineral residues.
- pH
- Titration
- Conductivity
- Turbidity




JCB
November 17, 2010 21

Content

- CIP process
- The human factor
- Analytics overview
- Turbidity


JCB
November 17, 2010 22

Turbidity Technique: Measurement Principle



JOB:
November 17, 2010 23

Turbidity Technique: What the Eye Can't See




- At low concentration the human eye is unable to differentiate
- But, the samples are different – shown by light scattering

JOB:
November 17, 2010 24

Laboratory Results

- At low concentration of whole milk powder samples in water, e.g. < 50 mg/L (50 ppm), the human eye is incapable of distinguishing between samples (hence the need for instrumentation)



JCB
November 17, 2010


Equipment: WTW Turb 430 IR Portable Turbidimeter



JCB
November 17, 2010

Laboratory Results


- Instrument performance confirmed in laboratory tests
- Figure shows plot of turbidity against whole milk powder concentration



JCB
November 17, 2010

Typical Graphs after CIP

- Three characteristic results were seen:
 - (i) Plateauing effect, before the end turbidity values very close to zero
 - (ii) Plateauing effect, at the end turbidity values greater than those of incoming rinsing water (problems with insoluble salts and minerals)
 - (iii) More random data distribution (problems caused principally by insoluble proteins)



JCB
November 17, 2010

6 questions to take home

- Is your process stable ?
(e.g. difference if cleaning solution recirculated)
- Are your samples representative ?
(e.g. larger & more representative quantities needed)
- Are you using the right methods ?
(e.g. ATP in rinsing water = not sensitive)
- Do you know the limits of the process ?
- Are you doing monitoring in sufficient frequency ?
- Are you using your data more than once ?

JCB
November 17,
2010 22